



# H8-Z67 Rework


1. Removed 74LS273 IC from **U21**.
2. Insert 74LS373 or 74F373 in **U21** position. Bend out pin **1** and pin **11** as shown below. Make sure that pin 1 and 11 does not touch or enter the IC socket.
3. Trim 74LS373 pin **1** and **11** to solder a wire on each pin as shown.
4. Solder a wire to pin **1** and a wire to pin **11** (use wire-wrap cable) as shown.



- Solder the cable attached to 74LS373 pin 1 to 74LS640 pin 1 (U11).



- Solder the cable attached to 74LS373 pin 11 to 74LS04 pin 10 (U25).
- Solder a wire to U25 pin 11 (74LS04). Solder the end of the wire to 74LS373 pin 11 (side 2 of the board) as shown.



- Please verify rework to ensure proper operation of the board.

# Board layout:

