

Carefully unsolder or cut the following jumper wires:

- () Wire between holes T1 and T2.
- () Wire between holes R1 and R2.
- () Wire between holes S2 and S3.
- () Wire between holes P2 and P3.
- () Wire between holes Z2 and Z3.
- () Cut three 3/4" bare wires. Use these wires in the next three steps.
- () Solder a 3/4" bare wire from hole P1 to hole P2.
- () Solder a 3/4" bare wire from hole Z1 to hole Z2.
- () Solder a 3/4" bare wire from hole X1 to hole X2.

