

H89-Z67 Board Rework

1. Solder a wire from RP1 10K PIN #10 to P2 PIN #12 as shown below.
2. This is required to support the H89-Z67 board on P506 and P512 connectors for the system to operate properly.

