

APPENDIX B.4.0 Centronics type (Epson) Printer Parallel cable wire list

Computer Side		Epson Printer Side	
DB-25 Pin Connector		36 Pin Connector (Amphenol 57-30360 or equivalent)	
5	STROBEL (PC7) ->	1	BROWN
18	DATA 1 ->	2	RED
17	DATA 2 ->	3	ORANGE
16	DATA 3 ->	4	YELLOW
15	DATA 4 ->	5	BLACK
1	DATA 5 ->	6	BLUE
2	DATA 6 ->	7	VIOLET
3	DATA 7 ->	8	GREY
4	DATA 8 ->	9	WHT-YELLOW
22	<- ACKNOWLEDGEL PC2	10	WHITE/BROWN
23	<- BUSY (PC3)	11	WHITE/BROWN
	NC	12	WH
	NC	13-15	
14	GROUND	16	WHITE
	NC	17-30	
20	INITL (PC4) ->	31	WHT/RED
	NC	32	
	NC	33-35	
	NC	36	

Where STROBEL Is the active LOW strobe to the receiving device line prompt indicating that data is ready and present at the DATA X lines

ACKNOWLEDGEL Is the active low signal from the receiving device indicating that the data has been accepted.