
13
14
15
1
20
89C430
40
21
CF Card
Power
Heat-Shrink
on Resistor
Leads
+5V
GND
1 2
5
8155
40 39 38 37
To
Ones
Switch
To
Tens
Switch
To
WP
0
To
WP
1
It is generally helpful
if there is a connector
between the WP switch
and the wiring on the
board. You can use
in-line or board mounted
connector for easy access
during assembly.
NOTE:
Pins numbers are
Value Weight.
Pin order varies
on different switches.
Either of the below
are common:
8 4 2 1 C
1 2 4 8 C
nc
C 8 4 2 1
X1
Switch
Conn
C 4 2 1
X10
Switch
Conn